

Parts & Instructions Sheet

What's In the box:

- **A** Copper Caddy (x 1) Dimensions H 33.5" x W 23.5" x D 7.75"
- B Angle Brackets (x8)
- C Fine Threaded Drill Point Screws (x 16)
- D Coarse Threaded Drill Point Screws (x 16)
- E 3/4" x 12" Velcro Straps (x3)
 - * For additional velcro straps: www.uline.com Part no. S-15757

A B C







D E





Installation Instructions

The Copper Caddy can be mounted anywhere you would like. We recommend mounting on the rear door of your work vehicle.

Step 1:

Place your Copper Caddy against the rear door and check for clearance from floor board to the bottom of the Copper Caddy. Mark your mounting placement with a marker.

Note: Allow 1/2" - 1" of clearance.





Step 2:

Use supplied angle brackets and drill point screws to secure the Copper Caddy to the rear door.

Note: Fine Threaded Drill Point screws are to be into the door or other metal mounting points. Coarse Threaded screws are to be drilled into the Copper Caddy.

Use (4) Brackets on each side when mounting on vehicle door. Only (2) brackets are necessary on each side of the Copper Caddy when resting on any floor and just needs mounted to a wall.

Fine Threaded Screws



Coarse Threaded Screws



Step 3:

That's It! Installation Complete! Enjoy Your Copper Caddy.

Partitions are cut out so you can use velcro straps around copper rolls to control noise and vibrations.

Optional:

Use wire ties around any rolls to keep tight.

Mounted Copper Caddy Silfos Holder



Disclaimer: Copper Caddy, Inc. is not liable for injury associated with installation and/or use of this product.